


PINZA ER32



D mm	L mm	A mm
33	40	3 / 20

Codice Code	Capacità Capacity mm
P032/03	2 - 3
P032/04	3 - 4
P032/05	4 - 5
P032/06	5 - 6
P032/07	6 - 7
P032/08	7 - 8

Codice Code	Capacità Capacity mm
P032/09	8 - 9
P032/10	9 - 10
P032/11	10 - 11
P032/12	11 - 12
P032/13	12 - 13
P032/14	13 - 14

Codice Code	Capacità Capacity mm
P032/15	14 - 15
P032/16	15 - 16
P032/17	16 - 17
P032/18	17 - 18
P032/19	18 - 19
P032/20	19 - 20